

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2/2008



	Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
Canon														
MD-110 DV					•									
DC100	•													
DC20	•				•									
DC21/DC22	•				•									
DC210/230					•									
DC-220V	•													
DC310	•													
DC320	•													
DC330	•													
DC40	•													
DC50	•				•									
Elura 100	•				•									
Elura 90	•				•									
EOS 20D w/kit lens							•							
EOS 30D w/small zoom							•	•	•					
EOS 40D w/Compact zoom							•							
EOS 5D w/compact zoom				•					•				•	
EOS Digital Rebel Xsi/450D w/compact zoom			•		•						•			
EOS Digital Rebel Xti/400D w/ compact zoom			•			•	•				•	•		
EOS Rebel XT/350D with kit lens		•	•			•	•				•	•	•	
FS10	•													
FS100	•													
FS11	•													
G30Hi/35Hi/45Hi												•		
HG10	•											•		
HR10		•			•									
HV10		•												
HV20		•			•									
MD110 DV					•									
MD160					•									
MV500/500i/550i/530i/600/600i/630i/650i		•												
MV750i/730i/700i/700		•												
MV850i	•				•									
MV890					•									
MV900					•									
MV930/940/950/960					•									
MVX100i/150i													•	
MVX1i		•												
MVX250i/200i/200	•											•		

*Availability may vary by country or location

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2/2008



	Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
MVX25i/20i		•										•		
MVX2i		•												
MVX330i	•				•									
MVX35i/30i		•												
MVX430					•									
MVX450/460					•									
Optura 300/MVX10i		•												
Optura Xi/MV3Xi														•
PowerShot S3 IS	•				•					•				
PowerShot S5 IS		•			•					•				
V60Hi/65Hi/75Hi				•									•	
Vixia HF10	•													
Vixia HF100	•													
Vixia HG10	•													
Vixia HR10		•												
Vixia HV20		•												
Vixia HV30		•												
ZR80/85/90		•												
ZR800					•									
ZR830/850					•									
ZR900	•				•									
ZR930					•									
ZR950					•									
Casio														
EXILIM Pro EX-F1		•			•					•		•		
Epson														
R-D1		•										•		
Fuji														
FinePix F5 Pro w/compact zoom									•			•		
FinePix IS 1		•								•				
FinePix IS Pro w/compact zoom									•					
FinePix S1000fd	•													
FinePix S100FS					•									
FinePix S5 Pro w/compact zoom									•					
FinePix S5700	•				•									
FinePix S5800	•				•									
FinePix S6000		•			•					•		•		
FinePix S6500fd		•			•					•		•		
FinePix S6900		•			•					•		•		
FinePix S700		•			•					•				
FinePix S8000fd	•				•					•				
FinePix S8100fd	•				•					•				

*Availability may vary by country or location


LOWEPRO DIGITAL SHOULDER BAG MATRIX 2/2008



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
	FinePix S9100/9600		•			•					•		•		
Hitachi	DZ-BD70A			•		•									
	DZ-BD7HA			•		•									
	DZ-BX37E		•												
	DZ-GX3100E		•			•									
	DZ-GX3200E		•			•									
	DZ-GX3300A		•												
	DZ-GX5020A/5080A		•			•									
	DZ-HS300A		•												
	DZ-HS500A		•												
	DZ-MV230		•										•		
	DZ-MV230A/270A/270E		•												•
	DZ-MV380		•				•								
	DZ-MV550/MV580		•				•								
	DZ-MV780A	•				•									
	HS300A/500A		•				•								
JVC	Everio GZ-MG145	•				•									
	Everio GZ-MG155/255	•				•									
	Everio GZ-MG26	•													
	Everio GZ-MG27/30/37/77	•				•									
	Everio GZ-MG555U	•				•									
	Everio GZ-MG575	•				•									
	Everio GZ-MG57EK	•				•									
	Everio GZ-MG77U	•				•									
	GR-AXM18													•	
	GR-D20EK/D50EK		•										•		
	GR-D250					•									
	GR-D33/72/93	•													
	GR-D350AA					•									
	GR-D370	•				•									
	GR-D650	•				•									
	GR-D73US	•				•									
	GR-D750/770/796	•				•									
	GR-D850/870	•				•									
	GR-DA30	•				•									
	GR-DVL120U											•			
	GR-DVM76/96	•													
	GR-FX15EK/SX25/FXM39E/SXM49/SXM58													•	
	GR-SXM38													•	

*Availability may vary by country or location

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2/2008

		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
			GR-XM250US/740U												
	GZ-HD3		•											•	
	GZ-HD7/HD7U									•				•	
	GZ-MG130	•													
	GZ-MG255	•				•									
	GZ-MG26	•				•									
	GZ-MG505HD	•				•									
	GZ-MG50S	•				•									
	GZ-MG555US			•											
Kodak	EasyShare P712	•									•				
	EasyShare P850	•									•				
	EasyShare P880					•					•				
	EasyShare V603					•					•				
	EasyShare Z612										•				
	EasyShare Z650	•				•					•				
	Easysshare Z710	•				•					•				
	EasyShare Z712 IS					•					•				
	EasyShare Z812 IS	•									•				
Leica	Digilux 3		•			•							•		
	M8 w/compact zoom			•			•						•		
	V-Lux 1			•			•						•		
Nikon	Coolpix 8800		•			•					•				
	D200 w/compact zoom									•				•	
	D2x/D2h (Body only)			•									•		
	D40 w/compact zoom			•			•					•	•		
	D50 w/kit zoom			•			•					•	•		
	D60 w/compact zoom		•			•						•	•		
	D70 w/kit zoom			•	•			•	•	•		•	•	•	
	D80 w/Compact Zoom			•	•			•	•	•		•	•	•	
Olympus	E-1 w/compact zoom			•	•	•						•		•	
	E3 w/compact zoom									•					
	E-510 w/compact zoom			•		•									
	Evolt E-330 w/compact zoom			•			•					•	•		
	Evolt E-400 w/compact zoom			•			•					•	•		
	Evolt E410 w/compact zoom		•			•									
	EVOLT E-500 w/compact zoom			•		•							•		
	SP-550UZ/560UZ	•													
	SP-570UZ		•								•				
Panasonic	AG-EZ50			•											•

*Availability may vary by country or location

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2/2008



	<i>Apex 100AW</i>	<i>Apex 110AW</i>	<i>Apex 120AW</i>	<i>Apex 140AW</i>	<i>Rezo 110AW</i>	<i>Rezo 120AW</i>	<i>Rezo 140AW</i>	<i>Rezo 160AW</i>	<i>Rezo 170AW</i>	<i>Rezo TLZ 10</i>	<i>Rezo TLZ 20</i>	<i>D-Res 40 AW</i>	<i>D-Res 50 AW</i>	<i>D-Res 240 AW</i>
AG-HSC1U		•												
HDC-DX1			•			•						•		
HDC-FX5			•		•							•		
HDC-HS9	•				•									
HDC-SD1/SD3		•			•									
HDC-SD9	•													
Lumix DMC-FZ18	•				•							•		
Lumix DMC-FZ50		•				•					•	•		
Lumix DMC-FZ7	•				•					•				
Lumix DMC-FZ8		•								•		•		
Lumix DMC-L1 w/compact zoom			•	•		•					•	•		
Lumix DMC-L10 w/compact zoom			•			•						•		
Lumix DMC-LC1/LC1B		•			•							•		•
NV-GS1/GS4/GS5						•								
NV-GS11B/15B	•					•						•		
NV-GS120B/200B	•											•		
NV-GS180	•				•									
NV-GS230	•				•									
NV-GS250/400B				•									•	
NV-GS27	•				•									
NV-GS280		•												
NV-GS320		•												
NV-GS500			•		•									
NV-GS60	•				•									
NV-GS70	•													
NV-GX7		•				•						•		
PV-DC152/252/352	•													•
PV-DV203	•											•		
PV-DV52/102/202/402				•									•	•
PV-DV702												•		•
PV-DV952			•									•		•
PV-GS120/200			•									•		
PV-GS150	•				•									
PV-GS180	•				•									
PV-GS300		•												
PV-GS31					•									
PV-GS320		•			•							•		
PV-GS35					•									
PV-GS39	•				•									

*Availability may vary by country or location

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2/2008



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
	PV-GS400				•										•
	PV-GS500			•											
	PV-GS50S												•		
	PV-GS55					•									
	PV-GS80/85		•			•									
	PV-GS9/12/14/15	•													
	PV-GS90	•													
	PV-L354/454													•	
	PV-SD5000			•									•		
	SDR-H18	•				•									
	SDR-H20/H250	•				•									
	VDR-D105					•									
	VDR-D210/230			•		•							•		
	VDR-D250		•			•									
	VDR-D300		•												
	VDR-D310			•									•		
	VDR-D50	•													
	VDR-M53		•			•									
	VDR-M75	•				•									
Pentax	*ist D w/kit zoom				•			•				•			
	*ist DL w/kit zoom			•			•					•	•		
	*ist DS w/kit zoom			•			•					•	•		
	*st DS 2 w/kit zoom			•			•					•	•		
	K100D w/compact Zoom				•			•				•	•	•	
	K10D w/Compact Zoom				•							•	•		
	K110D w/compact zoom				•			•				•	•	•	
	K200D w/compact zoom			•			•					•			
	K20D w/compact zoom						•					•			
RCA	CDS4100		•												
	CDS6300		•												
Ricoh	Caplio 500G Wide		•												
Rollei	d-24/d-30/d-530 Flex			•			•						•		
	Prego dk4010	•													
Samsung	Digimax Pro 815		•			•						•	•		
	GX-10 w/compact zoom				•			•					•		
	GX-1L w/compact zoom			•		•						•	•	•	
	GX-1X w/compact zoom			•		•						•	•	•	
	GX-20 w/compact zoom				•			•				•			
	SC-D173U	•				•									

*Availability may vary by country or location

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2/2008



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
	SCD180		•												•
	SCD363	•													
	SC-D372	•				•									
	SC-D575	•				•									
	SC-X105L				•										
	VP-D130		•				•								
	VP-D230/D270i			•		•									
	VP-D323/D325i						•								
	VP-D361i	•				•									
	VPD5000i		•					•					•		
	VP-D6040i/D6050i		•				•								
	VP-D80i				•				•					•	
	VP-D907i	•				•									
	VP-D963 WI					•									
	VP-D97	•	•				•						•		
	VP-DX10	•				•									
	VP-HMX10X					•									
	VP-W90/VPL700/VPL900				•				•					•	
Sharp	VL-AX1H/AX1U													•	
	VL-MC500H/500U		•										•		•
	VL-NZ55U/105U		•										•		•
	VL-Z1U/Z3U/Z5H/Z7U		•										•		
Sony	Alpha DSLR-A100 w/compact zoom				•			•				•	•	•	
	Alpha DSLR-A100K w/compact zoom				•			•				•	•		
	Alpha DSLR-A200 w/compact zoom			•		•						•	•		
	Alpha DSLR-A300 w/compact zoom			•			•					•			
	Alpha DSLR-A350 w/compact zoom						•					•			
	Alpha DSLR-A700 w/compact zoom												•		
	CCD-TRV108/308/318/608													•	
	CCD-TRV138			•		•							•		
	CCD-TVR128/328												•		
	DCR-DVD100/200/300		•												•
	DCR-DVD101/201/301		•												
	DCR-DVD105	•													
	DCR-DVD108		•			•									
	DCR-DVD203E		•			•									
	DCR-DVD205/305	•													
	DCR-DVD308		•			•									
	DCR-DVD403E		•			•									

*Availability may vary by country or location


LOWEPRO DIGITAL SHOULDER BAG MATRIX 2/2008



	<i>Apex 100AW</i>	<i>Apex 110AW</i>	<i>Apex 120AW</i>	<i>Apex 140AW</i>	<i>Rezo 110AW</i>	<i>Rezo 120AW</i>	<i>Rezo 140AW</i>	<i>Rezo 160AW</i>	<i>Rezo 170AW</i>	<i>Rezo TLZ 10</i>	<i>Rezo TLZ 20</i>	<i>D-Res 40 AW</i>	<i>D-Res 50 AW</i>	<i>D-Res 240 AW</i>
DCR-DVD405		•			•									
DCR-DVD408/508		•			•							•		
DCR-DVD505		•												
DCR-DVD605		•												
DCR-DVD608/708		•												
DCR-DVD705		•												
DCR-DVD92E	•				•									
DCR-HC1000/HC100D			•									•		•
DCR-HC28					•									
DCR-HC38/46/HC48					•									
DCR-HC47E					•									
DCR-HC65/85/85E	•											•	•	•
DCR-HC90E/96	•				•									
DCR-PC8	•					•								
DCR-SR100			•											
DCR-SR-200/300	•				•									
DCR-SR40	•				•									
DCR-SR42/SR62/SR82	•				•									
DCR-TRV128/328			•									•		
DCR-TRV138			•		•							•		
DCR-TRV140													•	
DCR-TRV240/340													•	
DCR-TRV280			•		•							•		
DCR-TRV38			•										•	•
DCR-TRV480			•		•							•		
DCR-TRV50/80			•										•	•
DCR-TRV530													•	
DCR-TRV740/840													•	
DCR-TRV950													•	
DSC-H1, H2, H5		•			•					•				
DSC-H7/H9		•			•					•				
DSC-R1				•				•			•	•		
DSR-PDX10													•	
HDR-CX7		•			•								•	
HDR-HC1							•						•	
HDR-HC3		•										•		
HDR-HC5		•			•							•		
HDR-HC7		•			•							•		
HDR-SR1			•			•						•		

*Availability may vary by country or location

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2/2008

		<i>Apex 100AW</i>	<i>Apex 110AW</i>	<i>Apex 120AW</i>	<i>Apex 140AW</i>	<i>Rezo 110AW</i>	<i>Rezo 120AW</i>	<i>Rezo 140AW</i>	<i>Rezo 160AW</i>	<i>Rezo 170AW</i>	<i>Rezo TLZ 10</i>	<i>Rezo TLZ 20</i>	<i>D-Res 40 AW</i>	<i>D-Res 50 AW</i>	<i>D-Res 240 AW</i>
			HDR-SR5/SR7		•			•							•
	HDR-UX1			•			•						•		
	HDR-UX5/UX7			•			•						•		
Thomson	VMD-160/170	•					•								
	VMD-270						•								
Vivitar	Vivicam V3500	•													